Алматы (7273)495-231 Ангарск (3955)60-70-56 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Благовещенск (4162)22-76-07 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Владикарказ (8672)28-90-48 Владимир (4922)49-43-18 Волоград (844)278-03-48 Волоград (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Иркутск (395)279-98-46 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3832)65-04-62 Киров (8332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Курган (3522)50-90-47 Липецк (4742)52-20-81 Казахстан +7(7172)727-132

Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новосуямецк (38493)20-46-81 Ноябрьск (3496)41-32-12 Новосибирск (383)227-86-73 Омск (3812)21-46-40 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Петрозаводск (8142)55-98-37 Псков (8112)59-10-37 Пермь (342)205-81-47

Киргизия +996(312)96-26-47

Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Саранск (8342)22-96-24 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Севастополь (8692)22-31-93 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Сургут (3462)77-98-35 Сыктывкар (8212)25-95-17 Тамбов (4752)50-40-97 Тверь (4822)63-31-35

Тольятти (8482)63-91-07 Томск (3822)98-41-53 Тула (4872)33-79-87 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Улан-Удэ (3012)59-97-51 Уфа (347)229-48-12 Хабаровск (4212)92-98-04 Чебоксары (8352)28-53-07 Челябинс (351)202-03-61 Череповец (8202)49-02-64 Чита (3022)38-34-83 Якутск (4112)23-90-97 Ярославль (4852)69-52-93

can@nt-rt.ru || https://comenda.nt-rt.ru/

### NEVER MORE WITHOUT.

# DHM LI

Automatic standalone pre-scrap module






## THE FIRST STEP IS ALWAYS THE MOST IMPORTANT

### Pre-scrap & prewash: best washing results start from here!

Sorting the dishware to be loaded into the washing machine is a crucial operation and must be performed properly, avoiding unnecessary waste of water, chemicals and time.


Automatic or manually operated, an effective prewashing action means you can count on cleaner water in the wash tank, a higher level of hygiene inside the washing chamber and, therefore, a more effective wash.



We, at Comenda, know what it means to cope with shifts at a fast pace, to work in a humid work environment and in contact with high temperatures, the struggle with daily machine cleaning operations.

We know it thanks to an ongoing open dialogue with our customers for over fifty years. This daily confrontation helps us to design solutions must serve to improve and simplify people's work.

If you want proof, discover DHM LI. Automatic standalone pre-scrap & prewash module.





Manual prescrap is a heavy operation for the staff that, during peak times, might not be able to cope with high volumes and dirty dishes, thus leading to a lack of care.

The operator must be properly trained on correct and responsible operations, avoiding unnecessary waste of resources and time.

Moreover, prolonged work in standing and by fumes of hot, dirty water laden with chemicals and odors in the wash up area could cause MSDs and other discomfort to the operator.



Flexible and adaptable, **DHM**LI is the retrofit solution for existing rack conveyour units, independently from their make.

It allows to adjust or reorganize your wash up area, by better organizing staff operations and creating a more comfortable work environment, reducing the amount of waste water, and significantly improving washing results!

With DHM LI it's never too late!

2 3



#### THE POWER OF SIMPLICITY

Comenda technology for automatic prescrap & prewash modules is **designed** to meet different needs and prepare the dishware for a consistent wash.

By simulating the effect of a prerinse hose on the dishware, it attacks food residues through three different actions: Hydration, Detachment, Elimination, featuring a combination of different jet patterns and projection angles of the upper and lower arms designed to remove soiled particles on the dishware. In this section dirt and food residues are "mechanically" removed from the dishware! Ready to wash!

In this section, dirt and food residues are "mechanically" removed from the dishware, making it ready to be washed!



### NEXT TO THE PEOPLE NEXT TO THE ENVIRONMENT



Comenda multi-stage prewash system guarantees a reduction in water consumption by up to 90%. Estimated water consumption with a prerinse hose is 10 liters/minute; Comenda DHM LI technology uses only 1 liter a minute!

Moreover, it allows to better organize the wash up staff work by eliminating the need of the prerinse sink and preventing operators from suffering from MSDs and other discomfort.

## THE BENEFITS OF AN AUTOMATIC PRE-SCRAP & PREWASH MODULE





### AUTOMATIC PRE-SCRAP MODULE: DMH LI/ALI

#### **INSPECTION DOOR**

and closing.

Double skin insulated doors, minimising the loss of energy and the noise level. The special shape of the seal allows the door to be cleaned automatically when opening

#### DEDICATED CONTROL PANEL

Lower control panel, simple and intuitive, with Emergency Stop Button.

#### BELT DRIVE CONTROL SYSTEM

Stainless steel central pawl bar system.

The rack is perfectly centred between the side guides for the most efficient and fluid operations.



#### LOWER ARMS PREWASHING

**UPPER ARMS PREWASHING** 

Stainless steel upper

prewashing arms with

negative embossed

anti-drip nozzles.

Stainless steel lower multiwash inspectable prewashing arms with negative embossed anti-drip nozzles.



#### TRIPLE FILTRATION SYSTEM

AISI 304 Stainless steel tank chassis and paneling. Deep-drawn tank with rounded corners. Self-draining vertical pump. Whole tank stainless steel filter and external basket filter.



#### MULTI-STAGE PREWASH TECHNOLOGY



### multiwash inspectable

Integrated Automatic Soil Removal.

**RED SYSTEM** 



HIGHER PRESSURE **WATER JETS** 

Thanks to the higher pressure water jets, the first upper arm removes the most stubborn stains.



V-SHAPED WATER JETS

Second upper arm and two lower arms with V-shaped jets to dissolve food residues.



**CASCADE WATER JET** 

The third upper arm, with a cascade water jet, completes the prescrapping action.









**RED - AUTOMATIC SOIL REMOVAL** 

Food residues produced during prewashing cycle are absorbed by a filter connected to the drain pump. Dirt is conveyed in a basket filter placed in an external tank. At the end of this process, food residues are separated from water.

The innovative RED System is entirely made in AISI 304 stainless steel; it can be removed and cleaned, even with the machine in operation, granting no downtime and the maximum hygiene.

6





#### DHM LI/ALI IS THE NEW BLACK

Need to prepare the dishware for a consistent wash, better organize your staff work, always counting on impeccable washing results while minimizing your operating costs?

DHM LI is the right solution for you.

Thanks to its extreme flexibility, it can be installed at any Comenda tunnel unit's entrance, current and superseded models, as well as for rack conveyor models from other manufacturers.







Heavy duty stand alone automatic prescrap station in straight configuration (DHM LI) installed at the entrance of a Comenda NEXT series rack conveyor (2020).

MANUAL PRE-SCRAP

PRE-SCRAP WITH DHM LI





Heavy duty stand alone automatic prescrap station in corner configuration (DHM ALI) installed at the entrance of a rack conveyor unit from other manufacturer.



## DHM ALI. THE SOLUTION IS AROUND THE CORNER

Stand alone prescrap station is also available in corner configuration (DHM ALI), to make the most of every inch.



8





#### TECHNICAL FEATURES DHM LI / ALI

Motor drive	0.18 kW
Wash Pump	0.86 kW
Recirculation Pump	0.1 kW
Drain Pump	0.1 kW
Tank Capacity	801
Tank Heating Element	6 kW
Power Supply	400 V 3N~
Frequency	50/60 Hz
Installed Load	7.24 kW

#### STANDARD FEATURES

- Autotimer enables the pumps to be stopped when there are no racks inside the module. The machine automatically starts to operate again when new rack is loaded. This solution achieves considerable energy savings.
- Inverter (1 speed) DHM LI works in full harmony with the rack conveyor unit it is connected to.
- Color Coding for identification of the module and its internal components. This helps with daily cleaning operations and machine preparation process, avoiding incorrect combinations and malfunctioning.
- Limit switch contactor.
- Door wipe seal for constant cleaning of the inside of the door
- 24V control circuit.







Алматы (7273)495-231 Ангарск (3955)60-70-56 Архангельск (8182)63-90-72 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Благовещенск (4162)22-76-07 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Владикавказ (8672)28-90-48 Владимир (4922)49-43-18 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06 Ижевск (3412)26-03-58 Иркутск (395)279-98-46 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61

Курск (4712)77-13-04 Курган (3522)50-90-47 . пецк (4742)52-20-81

Казахстан +7(7172)727-132

Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Самара (846)/200-43-16 Саранск (8342)/22-96-24 Санкт-Петербург (812)/309-46-40 Саратов (845)/249-38-78 Севастополь (8652)/22-31-93 Симферополь (3652)/67-13-56 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Ноябрьск (3496)41-32-12 Новосибирск (383)227-86-73 Омск (3812)21-46-40 Орел (4862)44-53-42 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Петрозаводск (8142)55-98-37 Сургут (3462)77-98-35 Сыктывкар (8212)25-95-17

Тамбов (4752)50-40-97 Тверь (4822)63-31-35

Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07 Томск (3822)98-41-53 Тула (4872)33-79-87 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Улан-Удэ (3012)59-97-51 Уфа (347)229-48-12 Хабаровск (4212)92-98-04 Чебоксары (8352)28-53-07 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Якутск (4112)23-90-97 славль (4852)69-52-93